

## Vorbohr-Schablone für SOL-Montagesysteme, Bohrer 6 mm - bitte Montageanleitung beachten.

Pre drilling template for SOL-mounting systems, driller 6 mm - please comply with the installation instruction.

